



CONXTD - Remote Set / Unset

Wire WebWay output to Intruder Panel key switch to trigger Set/Unset of Intruder Panel.

Technical Specification

Manufacturer	Scantronic / Eaton
Model	Menvier M1000
Version	
Minimum SPT software	V2.00
Misc Profile	Pro / Mini: None Nano: Nano - Remote OP/CL
Panel Wiring	Closed Circuit Loop (CCL)
Technical Notes	Panel must be connected to SPT serially and be signalling either SIA format or Hardwire Pins for alarm reporting.

Cable Connection

Pro/Mini WebWay	Panel
3A	A EOL
3B	A Zone

Nano WebWay	Panel
1a	A EOL
1b	A Zone

Panel Programming via Keypad

1. Enter Engineer mode.
2. Select Option 4 Program Circuits.
3. Then select circuit number (01).
4. Then (ENT) press (9) and then (ENT).
5. Exit Engineer mode.

CONXTD

Add to new CONXTD site

Select to enable set / unset feature when registering a site to CONXTD within Connections.

Add to existing CONXTD site

Submit a request using the 'Help' button in CONXTD Manager within Connections.